


North

Edge



6th Floor

South

Level	Area	Volume
Level 1		
Level 2		
Level 3		
Level 4		
Level 5		
Level 6		
Level 7		
Level 8		
Level 9		
Level 10		
Level 11		
Level 12		
Level 13		
Level 14		
Level 15		
Level 16		
Level 17		
Level 18		
Level 19		
Level 20		
Level 21		
Level 22		
Level 23		
Level 24		
Level 25		
Level 26		
Level 27		
Level 28		
Level 29		
Level 30		
Level 31		
Level 32		
Level 33		
Level 34		
Level 35		
Level 36		
Level 37		
Level 38		
Level 39		
Level 40		
Level 41		
Level 42		
Level 43		
Level 44		
Level 45		
Level 46		
Level 47		
Level 48		
Level 49		
Level 50		